



BOVALLS

dörrbyggeri

Installation instructions FSB door handle

The two longest screws are for external doors, the shorter screws are for interior doors.

The handle is fitted by pulling the two black discs towards each other.

Begin by cutting off the two pins from the plastic discs with a knife or similar.

Thread the screws into the countersunk holes in the discs and measure where the screws should be trimmed to fit through the small hole in the corresponding disc. Cut the two long screws.

Cut the screws with a small pair of pliers to suit the thickness of your door.

Thread the screws into the countersunk hole in the disc and screw firmly into the small hole in the corresponding disc. Do the same from the other side.

When the cover plates are installed, rotate the small opening downwards so that it is not visible and so that water cannot enter. This small opening means that a screwdriver can be inserted and used to remove the cover plate again.

Press the small sleeve/spacer onto the handle.

Press the handle in from both the in and outside. Ensure that the sleeve/spacer ends up in the right position. Lock the handle part which has a hex socket screw by screwing it in firmly. Screw it in so that the metal tag on the handle spindle is perforated.

